

Assembly instructions

1



The assembly foil serves to find the best position of the lenses. Pull off the paper from the stick on foil.

(foil on white paper)

2



Glue stick on foil from the outside onto the visor. Put on helmet and check position of the stick on foil.

3




Open visor and clean / degrease the inside area of the stick on foil with enclosed cleansing cloth.

4



Pull off protective paper from the lenses. Do not touch lenses on sticky side!!!

5



Lay the inside of the lenses onto your fingers. Attention: Do not touch sealant!!!

6



Glue lenses from the inside into the area of the stick on foil and push hard on sealing surfaces.

7



Pull off stick on foil and do not touch helmet for at least 24 hours at temperature no lower than 18° C or 64° F.

Attention: processing temperature not under 18° C!